



温度換算表

温度測定範囲: 1, 450~1, 750°C						Ring Color : White (HTH)					
Powder Batch # : 429/Date:2013年4月17日						Dimensions: ±20×10×7.0mm					
Ring dia-meter	Ring temperature	Ring dia-meter	Ring temperature	Ring dia-meter	Ring temperature	Ring dia-meter	Ring temperature	Ring dia-meter	Ring temperature	Ring dia-meter	Ring temperature
mm	°C	mm	°C	mm	°C	mm	°C	mm	°C	mm	°C
		19.38	1524	18.93	1582	18.48	1619	18.03	1656	17.58	1702
		19.37	1525	18.92	1583	18.47	1620	18.02	1657	17.57	1703
		19.36	1527	18.91	1583	18.46	1621	18.01	1657	17.56	1704
		19.35	1529	18.90	1584	18.45	1621	18.00	1658	17.55	1705
		19.34	1530	18.89	1585	18.44	1622	17.99	1659	17.54	1706
		19.33	1532	18.88	1586	18.43	1623	17.98	1660	17.53	1707
		19.32	1533	18.87	1587	18.42	1624	17.97	1661	17.52	1709
		19.31	1535	18.86	1588	18.41	1625	17.96	1662	17.51	1710
		19.30	1537	18.85	1589	18.40	1625	17.95	1663	17.50	1711
		19.29	1538	18.84	1590	18.39	1626	17.94	1664	17.49	1712
19.72	1450	19.28	1540	18.83	1591	18.38	1627	17.93	1665	17.48	1713
19.71	1453	19.27	1541	18.82	1592	18.37	1628	17.92	1666	17.47	1715
19.70	1456	19.26	1543	18.81	1593	18.36	1628	17.91	1667	17.46	1716
19.69	1458	19.25	1544	18.80	1593	18.35	1629	17.90	1668	17.45	1717
		19.24	1545	18.79	1594	18.34	1630	17.89	1669	17.44	1718
19.68	1461	19.23	1547	18.78	1595	18.33	1631	17.88	1670	17.43	1719
19.67	1463	19.22	1548	18.77	1596	18.32	1632	17.87	1671	17.42	1721
19.66	1466	19.21	1549	18.76	1597	18.31	1632	17.86	1672	17.41	1722
19.65	1468	19.20	1551	18.75	1598	18.30	1633	17.85	1673	17.40	1723
19.64	1471	19.19	1552	18.74	1599	18.29	1634	17.84	1674	17.39	1724
19.63	1473	19.18	1553	18.73	1599	18.28	1635	17.83	1675	17.38	1726
19.62	1476	19.17	1555	18.72	1600	18.27	1636	17.82	1676	17.37	1727
19.61	1478	19.16	1556	18.71	1601	18.26	1636	17.81	1677	17.36	1728
19.60	1480	19.15	1557	18.70	1602	18.25	1637	17.80	1678	17.35	1730
19.59	1482	19.14	1559	18.69	1603	18.24	1638	17.79	1679	17.34	1731
19.58	1485	19.13	1560	18.68	1604	18.23	1639	17.78	1680	17.33	1732
19.57	1487	19.12	1561	18.67	1604	18.22	1640	17.77	1681	17.32	1733
19.56	1489	19.11	1562	18.66	1605	18.21	1640	17.76	1682	17.31	1735
19.55	1491	19.10	1563	18.65	1606	18.20	1641	17.75	1683	17.30	1736
19.54	1493	19.09	1565	18.64	1607	18.19	1642	17.74	1684	17.29	1737
19.53	1495	19.08	1566	18.63	1608	18.18	1643	17.73	1685	17.28	1739
19.52	1498	19.07	1567	18.62	1608	18.17	1644	17.72	1686	17.27	1740
19.51	1500	19.06	1568	18.61	1609	18.16	1644	17.71	1687	17.26	1741
19.50	1502	19.05	1569	18.60	1610	18.15	1645	17.70	1688	17.25	1743
19.49	1504	19.04	1570	18.59	1611	18.14	1646	17.69	1689	17.24	1744
19.48	1506	19.03	1571	18.58	1611	18.13	1647	17.68	1690	17.23	1745
19.47	1507	19.02	1572	18.57	1612	18.12	1648	17.67	1691	17.22	1747
19.46	1509	19.01	1573	18.56	1613	18.11	1649	17.66	1692	17.21	1748
19.45	1511	19.00	1574	18.55	1614	18.10	1650	17.65	1694	17.20	1749
19.44	1513	18.99	1576	18.54	1615	18.09	1650	17.64	1695	17.19	1751
19.43	1515	18.98	1577	18.53	1615	18.08	1651	17.63	1696		
19.42	1517	18.97	1578	18.52	1616	18.07	1652	17.62	1697		
19.41	1519	18.96	1579	18.51	1617	18.06	1653	17.61	1698		
19.40	1520	18.95	1580	18.50	1618	18.05	1654	17.60	1699		
19.39	1522	18.94	1581	18.49	1618	18.04	1655	17.59	1700		

株式会社リート・ハンマー・ジャパン

〒105-0001 東京都港区虎ノ門3-10-4

虎ノ門ガーデン203

電話(03)5473-1680 FAX(03)5473-1685